

680-177 Non-EMI Assembly Kit

HOW TO ORDER

Sample Part Number	680-177	-8	-2
Basic Part Number	680-177 Non-EMI Assembly Kit		
Contact Size	See Table I		
Autoshrink Insulation Layers	1 = Single Layer 2 = Two Layers		

NOTES

- Assembly identified via tag and bag with manufacturer's name and P/N, space permitting.
- Termination kit is designed for use with 971-200 HV PwrLine contacts.
- For assembly procedure see GAP-205.
- For EMI shielded applications, see 680-179.

MATERIAL/FINISH

- Autoshrink tubing - duraelectric (.062 Wall), grey/N.A.
- Band - CRES/passivate
- Tape - glass cloth, flame retardant/N.A.

TABLE I

(1) GLASS CLOTH TAPE, FLAME RETARDANT SUPPLIED WITH ASSEMBLY			
(1) PRE-COILED BAND SUPPLIED WITH ASSEMBLY			
AUTOSHRINK INSULATION AS SUPPLIED			
FIRST LAYER AUTOSHRINK INSULATION RECOVERED			
SECOND LAYER AUTOSHRINK INSULATION RECOVERED			
Contact Size	Autoshrink Part Number		Band
	First Layer	Second Layer	
8	777-035-0156-5-8	777-004-01-6-8	601-601
6	777-035-0156-5-8	777-004-01-6-8	
4	777-004-01-5-8	777-004-02-6-8	
2	777-004-01-5-8	777-004-02-6-8	
0	777-004-02-5-8	777-004-02-6-8	
00	777-004-02-5-8	777-004-03-6-8	601-571
0000	777-004-02-5-8	777-004-03-6-8	