


**SERIES 80**  
**Contacts and Tools**  
**Product Selection Guide**



**About Series 80 Contacts**  
**Page C-3**



**Size #8 Power Contacts**  
**Page C-13**



**Size #23 Crimp Contacts**  
**Plus Installation and**  
**Termination Procedures**  
**Page C-4 thru C-9**



**Size #16 and #12**  
**(M39029/76, /78, /28, and**  
**/27) Coaxial Contacts for**  
**50 and 75 Ohm Cables**  
**Page C-14 and C-18**



**#23 Contact, 20 AWG**  
**Wire Adapter**  
**Page C-10**



**Size #12, Matched**  
**Impedance Contacts for**  
**75 Ohm Cable.**  
**Page C-17 and C-18**



**Size #20HD Crimp**  
**Contacts**  
**Page C-10**



**Size #8, 50 Ohm**  
**(2.5 GHz and 3 GHz),**  
**75 Ohm (4 GHz)**  
**Page C-19 thru C-28**



**Size #20 (M39029/58 & 57)**  
**Crimp Contacts**  
**Page C-11**



**Size #8 (M39029/60 and**  
**/59), Coax Contact for**  
**95 Ohm Coax Cable**  
**Page C-29 thru C-30**



**Size #16 (M39029/58 & 57)**  
**Crimp Contacts Page C-11**



**Size #8 M39029/113 and**  
**/114), Concentric**  
**Twinax Contacts for**  
**MIL-STD-1553 Databus**  
**Page C-31 thru C-32**



**Size #12 (M39029/58 & 57)**  
**Crimp Contacts**  
**Page C-12**




**Size #8, Differential**  
**Twinax Contacts**  
**Page C-33 thru C-37**



**Size #12 Pneumatic**  
**Crimp Contacts**  
**Page C-12**



**Size #8 Quadrax Contacts**  
**Page C-38 thru C-40**



SERIES 80  
**Contacts and Tools**  
Product Selection Guide




**Hand and Pneumatic  
Contact Crimp Tools and  
Positioners**  
Page C-41 thru C-43



**Contact Insertion and  
Extraction Tools**  
Page C-44




**Contact Retention Tester**  
Page C-45



**Size #8 Sealing Boots**  
Page C-45



**Dummy Contact Sealing  
Plugs (DCSP)**  
Page C-46



**Grommet Sealing Plugs**  
Page C-47