

- 6) Slide the sheath compression ring up and over the protective cable jacketing and the conical part of the internal compression ring.
- 7) Screw the backshell onto the connector using cushioned pliers (P/N: M120002) or a strap wrench (P/N: M120001) to avoid damaging the external plating. For correct torque, consult Table 7 on page 21.

TYPE BR CONNETOR ADAPTER

The BR connector features a cable clamp designed to properly secure UNI 4883 protective cable jacketing. It differs from the BF connector in that securing the jacketing is made easier with a metal clip (see figure 26).

Figure 26: BR Adapter with protective jacketing and metal clip

