

## Contacts and Tools

### Contacts and Tools

for Series 790, 791, 792, and  
793 Connectors

Section

**E**

### Contacts and Tools for Series 790, 791 & 793 Connectors

#### Contents

Contacts and Tools for Series 790, 791 and 793 Connectors .....	E-2, E-3
Size 12 Coax Contacts for Series 790, 791 and 793 Connectors .....	E-4, E-5
Size 16 Coax Contacts for Series 790, 791 and 793 Connectors .....	E-6, E-7
Pneumatic Contacts .....	E-8
Dummy Contact Sealing Plugs .....	E-9
Contacts and Tools for Series 792 Connectors .....	E-10
50 Ohm Coax Contacts for Series 792 Connectors .....	E-11
75 Ohm Coax Contacts for Series 792 Connectors .....	E-12
Twinax Contacts for Series 792 Connectors .....	E-13
Quadrax Contacts for Series 792 Connectors .....	E-14
El Ochito® Contacts for Series 792 Connectors .....	E-15, E-16

#### Crimp Contacts and Tools



Pages E-2, E-3

#### Size 12 Coax Contacts 50 and 75 Ohm



Page E-4, E-5

#### Size 16 Coax Contacts 50 Ohm



Pages E-6, E-7

#### Pneumatic Contacts, Sealing Plugs



Page E-8, E-9

#### Crimp Contacts and Tools



Pages E-10

#### 50 Ohm Coax Contacts



Pages E-11

#### 75 Ohm Coax Contacts



Page E-12

#### Twinax Contacts



Page E-13

#### Quadrax Contacts



Page E-14

#### El Ochito® Octaxial Contacts



Pages E-15, E-16