EL OCHITO® ASSEMBLY KITS AND TOOLS

Assembly Tools										
Contact PN	Inner Contact Crimp		Cable Shield Hex Crimp		Cable Shield Round Crimp			Key Alignment Tool	Ferrule Insertion Tool	Mating Tool
	Tool	Positioner	Tool	Hex Die	Tool	Positioner 1	Positioner 2			
858-003	809-015	859-101	809-129	859-007				600-236	607-018	600-263
858-004	809-015	859-101	809-129	859-007				600-235	607-018	600-264
858-005	809-015	859-101						600-236	607-018-2	600-263
858-006	809-015	859-101						600-235	607-018-2	600-264
858-009	809-015	859-101	809-129	859-007				600-244	607-018	600-265
858-010	809-015	859-101	809-129	859-007				600-243	607-018	600-266
858-014	809-015	859-101	809-129	859-007				600-244	607-018	600-265
858-015	809-015	859-101	809-129	859-007				600-243	607-018	600-266
858-016	809-015	859-101			809-134	859-184-2	859-184-3	600-236	607-018	600-263
858-017	809-015	859-101			809-134	859-184-1	859-184-2	600-235	607-018	600-264
858-026	809-015	859-101	809-129	859-007				600-236	607-018	
858-027	809-015	859-101	809-129	859-007				600-236	607-018	
858-028-01	809-015	859-101	809-129	859-007				600-236	607-018	600-263
858-028-02	809-015	859-101			809-134	859-184-2	859-184-3	600-236	607-018	600-263
858-029-01	809-015	859-101	809-129	859-007				600-235	607-018	600-264
858-029-02	809-015	859-101			809-134	859-184-1	859-184-2	600-235	607-018	600-264
858-030-02	809-015	859-101	809-129	859-007				600-236	607-018	600-263
858-031-02	809-015	859-101	809-129	859-007				600-236	607-018	600-264
858-035-01	809-015	859-101	809-129	859-007				600-243	607-018	600-266
858-035-02	809-015	859-101	809-129	859-186				600-243	607-018	600-266
858-037	809-015	859-101	809-129	859-007				600-243	607-018	600-266
858-038-01	809-015	859-101	809-129	859-007				600-244	607-018	600-265
858-038-02	809-015	859-101	809-129	859-186				600-244	607-018	600-265
858-039	809-015	859-101	809-129	859-007				600-244	607-018	600-265
858-042	809-015	859-101						600-235	607-018-2	600-264
858-043	809-015	859-101						600-274	607-018-2	600-267
858-045	809-015	859-101	809-129	859-007				600-274	607-018	600-267
858-046	809-015	859-101	809-129	859-007				600-235	607-018	600-264
858-047-01	809-015	859-101	809-129	859-007				600-274	607-018	600-267
858-047-02	809-015	859-101			809-134	859-184-2	859-184-3	600-274	607-018	600-267
858-048-01	809-015	859-101	809-129	859-007				600-235	607-018	600-264
858-048-02	809-015	859-101			809-134	859-184-2	859-184-3	600-235	607-018	600-264
858-049	809-015	859-101	809-129	859-007				600-274	607-018	600-267
858-050	809-015	859-101	809-129	859-007				600-235	607-018	600-264
858-051	809-015	859-101						600-274	607-018-2	600-267
858-052	809-015	859-101						600-235	607-018-2	600-264
858-055	809-015	859-101	809-129	859-007				600-244	607-018	600-265
858-056	809-015	859-101	809-129	859-007				600-243	607-018	600-266
858-057-01	809-015	859-101	809-129	859-007				600-244	607-018	600-265
858-057-02	809-015	859-101	809-129	859-186				600-244	607-018	600-265

© 2022 Glenair, Inc • 1211 Air Way, Glendale, CA 91201 • 818-247-6000 • www.glenair.com • U.S. CAGE code 06324 • El Ochito® Octaxial Contacts
Dimensions in Inches (millimeters) are subject to change without notice.

Assembly Tools

Assembly Tools										
Contact PN	Inner Contact Crimp		Cable Shield Hex Crimp		Cable Shield Round Crimp			Key Alignment Tool	Ferrule Insertion Tool	Mating Tool
	Tool	Positioner	Tool	Hex Die	Tool	Positioner 1	Positioner 2			
858-058-01	809-015	859-101	809-129	859-007				600-243	607-018	600-266
858-058-02	809-015	859-101	809-129	859-186				600-243	607-018	600-266
858-059	809-015	859-101	809-129	859-007				600-244	607-018	600-265
858-060	809-015	859-101	809-129	859-007				600-243	607-018	600-266
858-061	809-015	859-101						600-244	607-018-2	600-265
858-062	809-015	859-101						600-243	607-018-2	600-266
858-063	809-015	859-101						600-236	607-018-2	600-263
858-064	809-015	859-101						600-235	607-018-2	600-264
858-065	809-015	859-101						600-236	607-018-2	600-267
858-066	809-015	859-101						600-235	607-018-2	600-264
858-067	809-015	859-101						600-274	607-018-2	600-267
858-068	809-015	859-101						600-235	607-018-2	600-264
858-069	809-015	859-101						600-236	607-018-2	600-263
858-070	809-015	859-101						600-235	607-018-2	600-264
858-071	809-015	859-101						600-236	607-018-2	600-267
858-072	809-015	859-101						600-235	607-018-2	600-264
858-073	809-015	859-101						600-236	607-018-2	600-267
858-074	809-015	859-101						600-235	607-018-2	600-264

Inner Contact Crimp Tools

809-015
(M22520/2-01)

859-101
(K1906)

Cable Shield Crimp Tools

809-129
(M22520/5-01)

859-007 859-186
(M22520/5-45)

859-134
(GS206)

Removal Tool



859-184

859-049
(M81969/14-12)

Key Alignment Tools*

600-235 & 600-243
Socket contact



600-236, -244, & -274
Pin contact

Ferrule Insertion Tool

607-018: Type 1 Contacts
607-018-2: Type 2 Contacts

Jumper Cable Mating Adapters**



600-264 & -266
Socket Contact



600-263, -265, & -267
Pin Contact

* Only for use when assembling El Ochito contacts. Consult factory for available alignment inspection tools for existing assemblies.
** See page 50 for details

© 2022 Glenair, Inc • 1211 Air Way, Glendale, CA 91201 • 818-247-6000 • www.glenair.com • U.S. CAGE code 06324 • El Ochito® Octaxial Contacts

Dimensions in Inches (millimeters) are subject to change without notice.