

600-076, 600-077, 600G004, 600G007 Tools for Connector/Backshell Assembly Torque Wrenches

ANALOG HAND-HELD TORQUE WRENCH



600G004 Hand-Held Torque Wrench with Analog Readout

Torque wrench features a 3/8" drive head and rotatable analog readout. Features a lighted and audible electric signal and is adjustable to desired torque level from 0 to 150 inch pounds. Requires 9 volt battery (included).

ANALOG TORQUE WRENCH AND BENCH STAND



600G007 Bench-Mount Torque Wrench with Analog Readout

Torque wrench features a 3/8" drive head and rotatable analog readout. Features a lighted and audible electric signal and is adjustable to desired torque level from 0 to 150 inch pounds. Requires 9 volt battery (included).

ANALOG HAND-HELD, HIGH TORQUE WRENCH



600-076 Hand-Held High Torque Wrench with Analog Readout

Torque wrench features a dual sided 3/8" drive head for hand or bench mount use. Features a lighted electric signal and is adjustable to desired torque level from 20 to 360 inch pounds. Requires two Panasonic SR44W or equivalent batteries

ANALOG HIGH TORQUE WRENCH AND BENCH STAND



600-077 Bench-Mount Torque Wrench with Analog Readout

Torque wrench features a 3/8" drive head and analog readout. Lighted electric signal indicator and is adjustable to desired torque level from 20 to 360 inch pounds. Requires two Panasonic SR44W or equivalent batteries

© 2010 Glenair, Inc. MIL-DTL-38999 Cylindrical Connectors CAGE CODE 06324

Printed in U.S.A.