



**APPLICATION NOTE**

Cage Code:  06324	Document Description APPLICATION NOTE Design & Installation of VersaLink PCB Connectors	Document #: AN0005 Revision: 1 Page 1 of 6
-------------------------	---	--

**APPLICATION NOTE**  
**Design & Installation of VersaLink PCB Connectors**

WRITTEN BY: \_\_\_\_\_ DATE: 05/06/2021  
 Bryan Samowitz

APPROVED BY: \_\_\_\_\_ DATE: 05/06/2021  
 Guido Hunziker

THIS COPYRIGHT DOCUMENT IS THE PROPERTY OF GLENAIR INC. AND IS FURNISHED ON THE EXPRESS CONDITION IT IS NOT TO BE DISCLOSED, PRODUCED IN WHOLE OR PART, OR USED TO SOLICIT QUOTATIONS FROM COMPETITIVE SOURCES, OR USED FOR MANUFACTURE BY ANYONE OTHER THAN GLENAIR INC. WITHOUT THE WRITTEN PERMISSION OF GLENAIR INC. THE INFORMATION HEREIN HAS BEEN DEVELOPED AT PRIVATE EXPENSE AND MAY BE USED FOR THE PURPOSES OF ENGINEERING EVALUATION AND FOR INCORPORATION INTO TECHNICAL SPECIFICATIONS AND OTHER DOCUMENTS WHICH SPECIFY PROCUREMENT OF PRODUCTS FROM GLENAIR INC.



1211 AIRWAY, GLENDALE, CALIFORNIA 91201

**APPLICATION NOTE**

**Design & Installation of VersaLink Connectors**

CODE NUMBER 06324	SIZE A	<b>AN0005</b>	REV. 1
SCALE N/A		SHEET 1 OF 6	

Cage Code: 06324	Document Description APPLICATION NOTE Design & Installation of VersaLink PCB Connectors	Document #: AN0005 Revision: A Page 2 of 6
---------------------	---	--

## REVISION HISTORY

REVISION	DATE	REVISED PAGES	REVISIONS
A	05/06/21		Released

Cage Code: 06324	Document Description APPLICATION NOTE Design & Installation of VersaLink PCB Connectors	Document #: AN0005 Revision: A Page 3 of 6
---------------------	---	--

## Table of Contents

1.0	Purpose .....	4
2.0	Referenced Documents .....	4
3.0	Responsibility .....	4
4.0	Methods of Performance Optimization.....	5
4.1	PCB Layout & Design .....	5
4.2	Installation onto Board.....	6
4.3	Trace Routing .....	6
4.4	Board Material .....	6
4.5	Other Considerations .....	6

## Table of Figures

Figure 1 – Optimized PCB Layout.....	5
Figure 2 – Optimized PCB Cross Section .....	5

Cage Code: 06324	Document Description APPLICATION NOTE Design & Installation of VersaLink PCB Connectors	Document #: AN0005 Revision: A Page 4 of 6
---------------------	---	--

## 1.0 Purpose

This document describes the proper way to design and install VersaLink PCB connectors & contacts onto a PCB to achieve optimal signal integrity.

## 2.0 Referenced Documents

Document Number/Name	Description
GVLM-BR/BS & Similar	VersaLink MicroD PCB Connectors
853-052/054, 853-065/067, 853-079/080 & Similar	VersaLink Bridge PCB Connectors

**Table 1. Reference Documents**

## 3.0 Responsibility

This document is the responsibility of the Engineering team.

## 4.0 Methods of Performance Optimization

### 4.1 PCB Layout & Design

To achieve optimal impedance matching at the PC tail/PCB transition, we recommend the follow layout:




Figure 1 – Optimized PCB Layout




Figure 2 – Optimized PCB Cross Section

Cage Code: 06324	Document Description APPLICATION NOTE Design & Installation of VersaLink PCB Connectors	Document #: AN0005 Revision: A Page 6 of 6
---------------------	---	--

## 4.2 Installation onto Board

Trim the PC tails so a stub length of .020 inches or less is obtained per Figure 2. This minimizes the length of capacitive stubs, which lower impedance and cause the signal to resonate.

## 4.3 Trace Routing

Route the traces for the high-speed lines on the opposite side of the PCB from the connector to further reduce the length of capacitive stubs.

The signal trace width needed for the desired impedance is dependent on the PCB Stack-up, PCB material, and whether the traces are routed as differential pairs or single-ended lines.

It is recommended that the trace be tear drop shaped as it comes off the solder pad.

## 4.4 Board Material

The dimensions provided are based on using a board material with a Dk value of 3.00.

## 4.5 Signal Plated Through Holes

For the  $\varnothing.0200$  PTH – The important part of this is for the hole to be drilled with a #74 drill, resulting in a .0225 starting hole diameter, which controls the gap between the PTHs. The final hole can be as small as  $\varnothing.017$  inches.

## 4.6 Other Considerations

When being used in a connector that does not have PCB stand-offs, design for the PCB to be .020 inches from the base of the VersaLink PCB per Figure 2.

Figure 1 – The two ground holes on the .175 spacing only apply to the 853 VersaLink Bridge connectors. They should not be included for any other VersaLink Connector.

The board design described by this document does not meet the requirements of IPC-A-610 Class 3 due to the size of the signal solder pad.