

Series 62 Saddle Clamps

Selection Guide




Series 62 Saddle Clamps

General Purpose Saddle Clamps provide strain relief for jacketed cable. Saddle bars have tapped threads. Tighten saddle bars until the cable is secured.


Self-Locking Saddle Clamps are recommended for aircraft wiring harnesses with open wire bundles. Anti-decoupling mechanism provides audible detented coupling and prevents backoff under high vibration. Full radius saddle bars have self-locking SST clinch nuts. Wrap wire bundle with tape or use rubber bushing. Tighten saddle bars until fully seated on clamp frame. Full radius saddles should be fully bottomed onto frame.

EMI Braid Socks feature a length of shield braid terminated to a nickel-plated brass EMI adapter. Aluminum, stainless steel or composite. Self-locking, suitable for high vibration environments.


General Purpose



Self-Locking



EMI Braid Sock



Series 62 Saddle Clamps

Saddle Clamp Styles



Series 62 Saddle Clamps

Selection Guide

Adapter Code
A
AS50151 crimp
AS95234
MIL-DTL-26482 Ser. II
MIL-DTL-83723 Ser. III



Saddle Clamp
Spin Coupling
620A*046
Page 62-4



Saddle Clamp
Self-Locking
620A*038
Page 62-5



Saddle Clamp
Composite
620A*042
Page 62-6



Saddle Clamp
EMI Braid Socket
319A*175
Page 62-7



Saddle Clamp
EMI Braid Socket, Composite
319A*201
Page 62-9

Adapter Code
B
AS50151 Solder
with Endbell



Saddle Clamp
Style A Light Duty
620-053A**
Page 62-11



Saddle Clamp
Style C Environmental
620-053C**
Page 62-11



Saddle Clamp
Style H Heavy Duty
620-053H**
Page 62-12

Adapter Code
E
MIL-DTL-26500



Saddle Clamp
Direct Coupling
620ES050
Page 62-39

Adapter Code
F
MIL-DTL-38999
Series I and II



Saddle Clamp
Spin Coupling
620F*012
Page 62-13



Saddle Clamp
Self-Locking
620F*038
Page 62-14



Saddle Clamp
Composite
620F*042
Page 62-15



Saddle Clamp
EMI Braid Socket
319F*175
Page 62-16



Saddle Clamp
EMI Braid Socket, Composite
319F*201
Page 62-18

Adapter Code
G
MIL-DTL-28840



Saddle Clamp
Spin Coupling
620G*051
Page 62-38

Series 62 Saddle Clamps

Selection Guide

Adapter Code

H

MIL-DTL-38999
Series III and IV

Adapter Code

M

Series 80
Mighty Mouse

Adapter Code

P

Series 970
PowerTrip

Adapter Code

V

Series 806
Mil-Aero